



HOW TO TAP YOUR KEG

1. Unwrap the hose from the pump
2. Place the base of the tap into the top of the keg. Lining the two slots on the pump with the two knobs on the top of the keg.
3. There are two styles of taps, one has metal or black plastic “wings”, the other has a white plastic lever. Turn the “wings” or lever on the pump clockwise with both hands. On a lever style pump, the handle must be pulled out, then down, and locked into position. The pump is now engaged and you can dispense the beer. Just depress the black faucet that is on the end of the hose. You must depress the faucet completely and pour the beer down the side of the glass or you’ll end up with just foam.
4. While beer is flowing do not pump air into the keg. When beer ceases to flow, you have to pump additional air into the keg. Do this by using the black knob on the top of the pump. Pull the knob up and then push back down, do this until you have reached the desired flow rate.
5. Enjoy our handcrafted beer by drinking responsibly.
6. **Empty the keg completely before you return it** by flipping the lever on the faucet up all the way. It will stay in the open position while air is pumped into the keg. It is a lot easier to transport an empty than a partially empty one. We cannot use any beer that may be leftover, anyway.
7. When the keg is empty, lift up the lever then twist the lever or “wings” of the pump counter-clockwise with both hands until the pump comes off. Removing the pump will minimize the risk of damaging the pump and/or keg during transportation.